

Nitrogen Calibration Sources with Gauge Connection

Self contained nitrogen source includes all connections and hoses to connect directly to a pressure gauge or calibrator

Features

- Proprietary pressure balanced fine adjustment piston allows for extremely precise, finger-tip control of pressure at 0.03 psi (2 mbar) or 3000 psi (210 bar) or any range in between.
- Easily refillable nitrogen cylinder holds enough gas for multiple calibrations
- Nylon bag to hold hose and fittings attached to inside of lid
- Includes storage compartment in control panel for pressure reference test gauge
- Low volume Quick-test hose, gauge adapter and process connection can be attached to NPAK without thread sealant or a wrench
- Designed to meet US Department of Transportation (DOT) and Canadian Transport Canada (TC) standards
- CE Approved for use in European Union - Designed to meet Pressure Equipment Directive (PED) and Transportable Pressure Equipment (TPED) standards
- Made in USA



Nitrogen Calibration Sources with Gauge Connection

Select a model for more information

Model	Pressure Range	Gauge Adapter	Gauge Included	Hoses Included (2)	Hose Adapters (2)
NPAK-1MBA-6-3	0 - 3000 PSI	1/8" Male NPT	None	6 ft, 3 ft	1/4" Male NPT
NPAK-2MBA-6-3	0 - 3000 PSI	1/4" Male NPT	None	6 ft, 3 ft	1/4" Male NPT
NPAK-2FBA-6-3	0 - 3000 PSI	1/4" Female NPT	None	6 ft, 3 ft	1/4" Male NPT
NPAK-2FBA-RG-2m-1m	0 - 3000 PSI	1/4" Female BSPP	None	2 m, 1 m	1/4" Female BSPP
NPAK-3FBA-RG-2m-1m	0 - 3000 PSI	3/8" Female BSPP	None	2 m, 1 m	1/4" Female BSPP
NPAK-4FBA-RG-2m-1m	0 - 3000 PSI	1/2" Female BSPP	None	2 m, 1 m	1/4" Female BSPP